



## Verifying Settings for Static IP Address

1. Press the “Settings” button on the phone
2. Select option 3 for “Network Configuration”
3. Go to option 30 “DHCP Enabled”—This should say “No”
  - a. If not, while number 30 is highlighted, press \* \* # quickly.
  - b. You will see a button appear that says “Yes”---Press this button
4. Before you save, scroll up to option 6 “IP Address”
  - a. Press \*\*# quickly.
  - b. Press the edit button and enter IP address.
  - c. Once entered, press the “Validate” button.
5. Scroll down to option 7 Subnet Mask.
  - a. Confirm 255.255.255.0
  - b. If not, while number 7 is highlighted, press \*\*# quickly.
  - c. Then enter 255\*255\*255\*0.
  - d. Once entered, press the “Validate” button.
7. Scroll down to option 8 TFTP Server 1 and see if there is a number in this field. The number should read “64.193.113.113”
  - a. If no, while number 8 is selected, press the edit button and under “new TFTP Server 1” enter “64\*193\*113\*113”
  - b. Once entered, press the “Validate” button.
  - c. Press the Save Button
8. Press “Exit” or “Cancel” until you get back to the main menu where phone is configuring and press “\* \* # \* \*”
9. The clock should start spinning and phone should reboot.