



Verifying Settings for DHCP

1. Press the “Settings” button on the phone
2. Select option 3 for “Network Configuration”
3. Go to option 30 “DHCP Enabled”—This should say “Yes”
4. Go to option 32 “Alternate TFTP”—This should say “Yes”
 - a. If not, while number 32 is highlighted, press * * # quickly.
 - b. You will see a button appear that says “Yes”
 - c. Press this button
5. Before you save, scroll up to option 8 “TFTP Server 1” and see if there is a number in this field. The number should read “64.193.113.113”
 - a. If no, while number 8 is selected, press the edit button and under “new TFTP Server 1” enter “64*193*113*113”
 - b. Once entered, press the “Validate” button.
6. Press The Save Button
7. Press “Exit” or “Cancel” until you get back to the main menu where phone is configuring and press “* * # * *”
8. The clock should start spinning and phone should reboot.